



Changing the gain resistor in the 2102 Breakdown / Hipot Adapter

To modify the gain of the 2102 adapter, the following resistor should be changed :



To modify the gain, replace resistor **R10** with a **150kΩ** resistor